

JBL

**Casque audio
TUNE 760NC BLANC**

QUICK START GUIDE

TUNE750BTNC



WHAT'S IN THE BOX




POWER ON & CONNECT



MANUAL PAIRING




BUTTON COMMAND



WIRED LISTENING



MULTI-POINT CONNECTION



- TO SWITCH MUSIC SOURCE, PAUSE THE MUSIC ON THE CURRENT DEVICE AND SELECT PLAY ON THE 2ND DEVICE.
- PHONE CALL WILL ALWAYS TAKE PRIORITY.
- IF ONE DEVICE GOES OUT OF BLUETOOTH RANGE OR POWERS OFF, YOU MAY NEED TO MANUALLY RECONNECT THE REMAINING DEVICE.
- SELECT "FORGET THIS DEVICE" ON YOUR BLUETOOTH DEVICES TO DISCONNECT MULTI-POINT.

1ST BLUETOOTH DEVICE

CHOOSE "JBL TUNE750BTNC" TO CONNECT

2ND BLUETOOTH DEVICE

CHARGING



LED BEHAVIORS

- LOW BATTERY
- CHARGING
- FULLY CHARGED
- POWER ON/OFF
- BT CONNECTING
- BT CONNECTED
- ANC ON

