

# PHILIPS

# MIXEUR BATTEUR

# HR265790

## MANUEL D'UTILISATION





Besoin d'aide ?

Rendez-vous sur votre communauté <https://sav.darty.com>



**PHILIPS**



HR2621, HR2650  
HR2651, HR2652  
HR2653, HR2655  
HR2656, HR2657



HR2621, HR2652  
HR2655, HR2657




HR2653



		MAX.	⌚	🔌
🍹	🍌 🍌 🍌 🍌	100-200 g	30 sec.	🔌
	🥛 🍌 🍌	100-400 ml	60 sec.	🔌
	🍌 🍌 🍌	100-500 ml	60 sec.	🔌
	🍌 🍌 🍌	100-1000 ml	60 sec.	🔌
🍷	🍷	250 ml	70-90 sec.	🔌
	🍷	4 x 🍷	120 sec.	🔌
🍷	🍷	250 ml	70-90 sec.	🔌
	🍷	4 x 🍷	120 sec.	🔌
	🍷	750 g	180 sec.	🔌
	🍷	750 g	120 sec.	🔌
XL 🍷	🍷	200 g	5 x 1 sec.	🔌
	🍷	200 g	5 sec.	🔌
	🍷	200 g	10 sec.	🔌
	🍷	30 g	10 sec.	🔌
	🍷	200 g	15 sec.	🔌
	🍷	200 g	30 sec.	🔌
	🍷	100 g	20 sec.	🔌
	🍷	80 g	30 sec.	🔌




HR2621, HR2652  
HR2653, HR2655, HR2657



HR2656  
HR2657




HR2650, HR2651, HR2652  
HR2653, HR2655, HR2656, HR2657




	1	2	3		
HR2656 HR2657		✓	✓	✓	
		✓	✓	✓	
		✓	✓	✓	
		✓	✓	✓	
		✓	✓	—	
		✓	✓	✓	

	MAX.			
HR2650 HR2651 HR2652 HR2653 HR2655 HR2656 HR2657		400 ml	60 sec.	
		400 ml	60 sec.	

HR2651  
HR2655



HR2651  
HR2655



	MAX.			
HR2651 HR2655		20 min		
		200 g	60 sec.	
		100 g		
		2 x 2 x 2 cm		



	✗	✗	✓
	✓	✗	✓
HR2621 HR2652 HR2655 HR2657	✗	✗	✓
HR2621 HR2652 HR2655 HR2657	✓	✓	✓
HR2653	✗	✗	✓
HR2653	✓	✓	✓
HR2621 HR2652 HR2653 HR2655 HR2657	✗	✗	✓
HR2656	✓	✓	✓
HR2621 HR2652 HR2653 HR2655 HR2657	✓	✓	✓
HR2656 HR2657	✗	✗	✓
HR2656 HR2657	✓	✓	✓
HR2650 HR2651 HR2652 HR2653 HR2655 HR2656 HR2657	✓	✓	✓
HR2651 HR2655	✓	✓	✓

