

PHILIPS

TONDEUSE

BT5520/16

MANUEL D'UTILISATION







Besoin d'aide ? Rendez-vous sur www.communaute.darty.com





PHILIPS

BT5520
BT5515














mm		mm		mm	
0.4	0.4	1.8	1.8	5	5
0.6	0.6	2	2	6	6
0.8	0.8	2.5	2.5	7	7
1	1	3	3	8	8
1.2	1.2	3.5	3.5	9	9
1.4	1.4	4	4	10	10
1.6	1.6	4.5	4.5		





mm		mm		mm	
10.4	10.4	11.8	11.8	15	15
10.6	10.6	12	12	16	16
10.8	10.8	12.5	12.5	17	17
11	11	13	13	18	18
11.2	11.2	13.5	13.5	19	19
11.4	11.4	14	14	20	20
11.6	11.6	14.5	14.5		

